Uppo/Pinta

Product info

In the ITP data group centres, the IT and electricity distribution spaces are located on top of each other. The side of the centre has a cable chute by the IT space for the wiring of the electricity distribution section. This makes it easy to connect a feed cable from the bottom. The IT space can be equipped with a wide variety of fittings, which enable several different uses. Available for both surface and flush mounting. The surface-mounted model contains the necessary feed-through flanges and a fixed back plate. When flush-mounted, the centre only rises 4mm above the wall surface!

Technical details

- Ue (V)
- ΙP

- fn
- lcw
- Material

- Breaker 1-pole C20
- 230/400
 - RJ -connector
 - 20C
 - Installation
 - Väri

<5**k**A **RAL9016**

Ku-Si





Phone numbers: Vaihde: 010 5727 501 Myynti: 0400 101 501 VAT. 0306687-3 FI03066873

